

	HI4050 model	Replace with HI6800 Part #
<i>With Display</i>	HI4050-PM-DC-EIP-NO-N0-N2-N3-NONE	HI6800-WC-PM1-DC-00
	HI4050-PM-DC-NO-NO-N0-N2-N3-NONE	HI6800-WC-PM1-DC-00
	HI4050-PM-AC-EIP-NO-N0-N2-N3-NONE	HI6800-WC-PM1-AC-00
	HI4050-PM-AC-NO-NO-N0-N2-N3-NONE	HI6800-WC-PM1-AC-00
<i>Without Display</i>	HI4050-DR-DC-EIP-NO-N0-N2-N3-NONE	HI6800-WC-DR-DC-00
	HI4050-DR-DC-NO-NO-N0-N2-N3-NONE	HI6800-WC-DR-DC-00
	HI4050-DR-AC-EIP-NO-N0-N2-N3-NONE	HI6800-WC-DR-AC-00
	HI4050-DR-AC-NO-NO-N0-N2-N3-NONE	HI6800-WC-DR-AC-00
<i>In Panel</i>	HI4050-PMWS:-DC-EIP-NO-NO-N2-N3-N4-NONE	HI6800-WC-PMWS1-DC-NSC
	HI4050-PMWS:-AC-EIP-NO-NO-N2-N3-N4-NONE	HI6800-WC-PMWS1-AC-NSC
	HI4050-PMWS:-DC-EIP-NO-NO-N2-N3-IT1-NONE	HI6800-WC-PMWS1-DC-IT1
	HI4050-PMWS:-AC-EIP-NO-NO-N2-N3-IT1-NONE	HI6800-WC-PMWS1-AC-IT1
<i>With Rate of Change</i>	HI4050-PM:-AC-EIP-NO-ROC-N2-N3-NONE	HI6800-ROCA-PM1-AC-00
	HI4050-PM:-DC-EIP-NO-ROC-N2-N3-NONE	HI6800-ROCA-PM1-DC-00
	HI4050-DR:-AC-EIP-NO-ROC-N2-N3-NONE	HI6800-ROCA-DR-AC-00
	HI4050-DR:-DC-EIP-NO-ROC-N2-N3-NONE	HI6800-ROCA-DR-DC-00

Note: Any 4000 Series models above ending with **NTEP** can be replaced with 6800 series to the right

Any 4000 Series models containing **ANA** or **DIO** must be replaced with a 6850 configured with the GPIO option